


CETTIG

Surface-mounted Downlight



To secure safety, a qualified electrician is required to install/remove the luminaire, in according with IEEE regulation and installation instructions.



CAUTION: Electric Shock.....




Don't stare at the operating light source.....




CAUTION: the luminaire must not be disposed of with household waste.....


Model	Power	Products Size
8961LED	10W/15W/20W	φ 96xH125mm
81251LED	25W/30W/40W	φ 125xH150mm
81801LED	50W/60W/70W/80W	φ 180xH210mm




8961LED




81251LED



81801LED




Luminaire not suitable for covering with thermally insulating material.




Luminaire can't recessed mounted into flammable material.


Installation:




1




2




3




4



5



6




7


The installation is completed.

Maintenance:


Pull out the fixture down from the ceiling.




1



2



3



4